



Sensoflex - Inkremental SFI-plus

Operating Instructions

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding






ENGINEERING YOUR SUCCESS.

Chapter	Contents	Page
1	Foreword to the Operating Instructions	3
2	Safety	3
3	Warranty	4
4	Transport and Assembly	5
5	After sales service	5
6	Technical description	6
7	Installation and fitting	8
8	Electrical connection	11
9	Service	13
10	Troubleshooting	13
12	Replacement Parts	15
13	Removal / Disposal	15

Explanation of Symbols and Notes

Notes which are highlighted by these symbols help to prevent injury to personnel. Please ensure that all users understand them.

Symbol	Explanation of Symbol
	Attention: This symbol is used if failure to comply carefully with operating instructions, operating sequences, etc. can lead to personal injuries, fatal accidents or damage to the plant.
	Information: Symbol for tips and notes to facilitate use of machine and to help to prevent damage.
	Attention: Danger of crushing

1 Foreword to the Operating Instructions

The purpose of these Operating Instructions is to assist you in familiarising yourself with the SFI-plus and to make use of the functions it has been designed for.

The Operating Instructions contain important advice so that you can use the SFI-plus safely, reliably and economically. Observance of these Operating Instructions will help you to avoid danger, reduce repair costs and downtime as well as to increase reliability and the service life of the SFI-plus.

These Operating Instructions need to be read and applied by all persons working with the SFI-plus, including:

- operating the unit, including setup work, trouble shooting during the work sequence, removal of production waste, servicing, handling as well as removing waste of hazardous materials (operating and auxiliary materials);
- maintenance (preventive maintenance, inspection, repairs)

In addition to the Operating Instructions and the mandatory regulations for accident prevention and environmental protection applicable in the user country and at the location of deployment, the standard technical rules and regulations for safe and professional work shall also be observed.

User's Responsibilities

The following is assumed to be the operator's/organisation's responsibility:

- compliance with EN 89/655 and the national applications
- compliance with the applicable national regulations for safety at work
- authorized use of SFI-plus
- correct applications of these operating instructions.

Commissioning of the OSP-P is forbidden until it has been established that the machine/plant in which it is to be installed complies with the requirements of the EC Machines Directives.

Copyright

Parker-Origa GmbH retains the copyright in these operating instructions.
Copyright 2008 ©

They must not be copied in full or in part, distributed or used in an unauthorized manner for competitive purposes or passed on to others. Contravention may lead to legal action.

Produkt Monitoring

Our goal is to supply safe, state-of-the-art products. Therefore we monitor our products constantly after delivery. Please inform us immediately of any recurring malfunctions or problems with the SFI-plus

2 Safety

The equipment has been constructed in accordance with state-of-the-art technology and current regulations. Special emphasis has been placed on the safety of operators. This has been confirmed in the manufacturer's statement.

In addition, all relevant rules and regulations apply as a matter of course, such as the applicable regulations for health and safety at work, generally accepted rules for the safe operation of machinery, the EU Directives, any special regulations of the respective country/state as well as any other relevant standards.

Authorized Use

The SFI-plus length measuring system has been designed exclusively for general distance measuring for industrial purposes, especially for determining the location of cylinder pistons and attached components. It may be suitable for other, similar measuring tasks.

Any applications beyond the above description are considered not in accordance with the design purpose. The manufacturer does not accept any liability for any damage resulting from such use and any associated risk must be borne by the user. As the SFI-plus can be used in a variety of applications, the responsibility for its specific application passes over to the user when such use commences.

Personnel

The SFI-plus has been constructed in accordance with state-of-the-art technology and the recognised safety rules and regulations. Nevertheless, it is possible that risks arise during the application of the equipment. For this reason, the units may only be fitted and operated by competent and trained personnel and only be deployed in accordance with the intended purpose. All persons involved in the fitting, operation, servicing, repair or dismantling of SFI-plus must have read and understood these operating instructions and in particular the section on 'Safety' of the operating instructions for OSP and/or similar drives or linear axles.

Conversions and alterations



The SFI-plus shall not be modified in its construction and safety aspects, without the prior written approval of **Parker-Origa GmbH**. Any such modifications carried out without approval will rule out all liability on the part of **Parker-Origa GmbH**.

The replacement of spare parts may only be carried out after consultation with our service technicians or by these technicians themselves. On principle, it is not permitted to take off or de-activate any safety or protection devices.

When installing special attachments, the assembly regulations of the manufacturer shall be observed as required.

The following regulatory instruments must be observed as a matter of course:

- relevant rules and regulations for accident prevention,
- generally recognised safety regulations,
- EU-Directives and
- country-specific provisions.

3 Warranty

We reserve the right to make alterations to these Operating Instructions as well as to technical details with reference to data and illustrations as contained in these Operating Instructions.

Parker-Origa GmbH issues no quality and durability guarantees or any guarantees for the suitability for certain purposes unless these are expressly agreed in writing.

Public statements, statements of quality or advertising are not statements of characteristics.

If the user wants to make a claim under the warranty, he needs to notify the fault immediately and describe it precisely in his statement of complaint. Under no circumstances is

Parker-Origa GmbH responsible for damage to the product itself or for consequential

damage caused by the product, as caused by incorrect and faulty handling of the product. Insofar as **Parker-Origa GmbH** is responsible for a fault, **Parker-Origa GmbH** may, at its discretion, either repair/modify the product or replace the item with a new one.

All SFI-plus are provided with an identification plate within the framework of ISO 9000, that is attached to an OSP-P. This identification plate shall not be removed or destroyed in any way.

A liability of Messrs **Parker-Origa GmbH** – irrespective of the legal reason – exists only in the event of intentional or gross negligence, culpable injury to life, body, health, in the event of deficiencies with malicious intent of deception or faults the absence of which has been expressly guaranteed.

Furthermore, the company is liable to the extent stipulated by the product liability law regarding personal injury or material damage on objects used privately. In the event of culpable violation of essential contractual obligations, **Parker-Origa GmbH** is liable also in the case of minor negligence, however, limited to the damage that could be foreseen under the contract.

Any other claims are ruled out.

No warranty shall apply in the event of non-observance of these Operating Instructions, the relevant legal provisions as well as further instructions of the supplier.

In particular, we are not responsible for stoppages caused by modifications by the customer or other persons. In such cases, we charge the normal repair costs. These are also charged for an inspection of the equipment where no fault can be found on the equipment.

This regulation also applies during the warranty period.

Users have no rights regarding the supply of previous equipment versions or regarding the upgrading of equipment to the current version.

The right to introduce technical modifications is reserved.

4 Transport and Assembly

Transport damage and missing parts are to be reported immediately and in writing to the transport company or to **Parker-Origa GmbH** or to the delivery company.



Any intermediate storage must not be outside but in dry, dust-free rooms that are free from vibrations.

Storage temperature –25° to +80° C.

5 After sales service

Spare parts and after sales service addresses

Refer to the last page of these Operating Instructions.

Spare parts list

For the purposes of preventive maintenance for the linear drives, we offer seal kit sets, service packages and spare parts (refer to Chapter 12 page 15).

Please observe our homepage: www.origa-service.com

6 Technical description


6.1 Technical data

The SFI-plus consists of a reading head with integrated electronic evaluation system and a magnetic measuring tape. The reading head records the position while being moved across the measuring tape.

It can only operate with the correct measuring tape for this system. It can be installed in any position. SFI-plus measuring tape dimensions For further information about application options please refer to the catalogue.


A type plate with CE symbol is affixed to the side of the reading head that faces away from the measuring tape and carries the following data:

- Identification number and type designation
- Elt. connection details
- Assignment of cables
- Year of manufacture



SFI-plus measuring tape dimensions

Dimensions for installation



Cylinder	A	B	C	G
OSP-P 25	32	39	23	5,5
OSP-P 32	37,5	46	30	6,5
OSP-P 40	42,5	50	34	6,5
OSP-P 50	49,5	55	39	6,5
OSP-P 63	59,5	65	49	10
OSP-P 80	72,5	80	64	12

6.2 Data and properties

Output function	Id.-Nr. 21210	Id.-Nr. 21211
Resolution	0,1 mm	1 mm
Pole length of measuring tape	5 mm	
Maximum speed	10 m/sec.	
Repeat accuracy	± 1 increment	
Distance of reading head to measuring tape	<= 4 mm	
Reading head position angle	<= 5 °	
Possible lateral deviation	<= ± 1,5 mm	
Switch output	PNP	
Electrical properties		
Operating voltage Ub	18 ... 30 V DC	
Voltage drop	<= 2 V	
Constant current per output	<= 20 mA	
Current input for Ub = 24 V, switched on, no load	<= 50 mA	
Short-circuit protection	yes	
Reverse pole protection	yes	
Protection against inductive cutoff current peaks	yes	
Inrush current suppression	yes	
EMC		
Electrostatic discharge	EN 61000-4-2, 6 kV, B	
Electromagnetic field	EN 61000-4-3, 10 V/m, A	
Fast transient burst (signal connections)	EN 61000-4-4, 1 kV, B	
Fast transient burst (DC connections)	EN 61000-4-4, 2 kV, B	
Surge resistance (signal connections)	EN 61000-4-5, 1 kV, B	
Surge resistance (DC connections)	EN 61000-4-5, 0,5 kV, B	
HF cable conducted	EN 61000-4-6, 10 V, A	
Magnetic field 50 Hz	EN 61000-4-8, 30 A/m, A	
Fault transmission	EN 61000-6-4	
Radiated fault transmission	EN 55011, group 1, A	
Mechanical properties		
Connection cable	PUR: 4 x 0,14 mm² black	
Length of cable	5m, integral, open ended	
Bending radius, moving	>= 36 mm	
Material of housing	Anodised aluminium	
Weight	ca. 0,165 kg	
Ambient conditions		
Protection type in accordance with EN 60529	IP67	
Ambient temperature range	-25 ... +80 °C	
Vibration in accordance with EN 60068-2-6	12 G, 10 to 2 kHz, 5 h per axis	
Broadband noise EN 60068-2-64	5 ... 2 kHz, 5 G, 0,5 h per axis	
Shock in accordance with EN 60068-2-27	100 g, 6 ms, 50 per axis	
Bump in accordance with EN 60068-2-29	5 g, 2 ms, 8000 shocks per axis	

7 Installation and fitting

7.1 Functional safety notes



Please observe the notes in the catalogue and/or in the operating instructions of the respective pneumatic unit / drive axle for instructions relating to mechanical fitting.

The fitting must always be carried out in such a way that the relevant regulations are complied with; the electric installation must comply with the following notes in accordance with EMC regulations:

- The cable between the reading head and the downstream electronics should not be longer than necessary.
- Only use screened cable, if possible twisted.
- All signal cables should be installed at the maximum possible distance to cables that are subject to faults, such as drive cable, inverter cable etc.
- Where appropriate, standard EMC filters should be fitted to the cable for the operating voltage of the reading head.
- The reading head should be installed with the maximum possible distance to drives, inverters etc. or protected from these with screening baffles if required.

All connections and operating parts must be accessible and the type plate in a readable position. The cable assignment is also described on the unit.



Any sources of danger existing between Parker-Origa products and customer equipment are to be eliminated by the user or to be made secure.

7.2 General

Where the SFI-plus has not already been fitted to a drive unit by **Parker-Origa**, the following should be observed:

The minimum and maximum permitted distance between reading head and measuring tape must not be exceeded in either direction at any time during the movement. The guide mechanism needs to be designed accordingly (see also page 10).

Reading head

The SFI-plus may only be installed in accordance with the specified type of protection (IP67). In addition, the reading head should be protected against impact, friction, solvents and temperatures below -25° and above $+80^{\circ}$ C.

Measuring tape

For technical reasons, the measuring tape has to be longer than the measured distance by approximately 10 mm on both sides. The measuring tape is supplied in rolls at certain lengths (unless already installed).

A metallic pair of scissors can be used to cut the measuring tape to the length required for the distance to be measured.



Avoid direct contact of measuring tape to magnets!

7.3 Fixing the measuring tape

The measuring tape is to be fixed to the OSP exclusively in the dovetail groove of the cylinder tube or drive profile.

For other applications (linear drives, mech. or elt. axes etc.) the fixing should be similarly, as required by the situation.




Attention!

The active side of the measuring tape (brown) must be facing the active side of the reading head (opposite the type plate).

This simple fitting method can only be recommended in a relatively protected environment. Otherwise there is a risk of the bonding to become detached. If necessary, suitable commercially available adhesives can be used.

Arrangement of reading head and fixing of measuring tape, bonded with self-adhesive tape




Fitting steps:



Attention!

In order to achieve optimum adhesion it is necessary to remove all foreign substances, such as oil, grease, dust etc. Use cleansing agents that do not leave a residue, such as acetone or alcohol. Ideally, the measuring tape should be glued into place at a temperature between 20° and 30° C.

- Clean the fitting surface (1) thoroughly (degreasing) and optionally mark the linear position, after aligning it well.
- The measuring tape (4) is supplied with double-sided adhesive tape (3).
- Remove protective film (2).
- Place the measuring tape (4) onto the fitting surface (1).
- Attach red protection film (5) onto the brown side of the measuring tape (4).



Process of attaching the tape

7.4 Fitting the reading head

The mechanical configuration and fitting angle need to comply with the specified tolerances between the reading head and the measuring tape for the whole length of travel:




max. distance ≤ 4.0 mm !

The reading head must not come in contact with the measuring tape.

The reading head is fitted to the OSP cylinder series with the appropriate connection sets (see also the drawing of individual spare parts on page 15).

- Attach the reading head with two M3 screws (insertion depth max. 4 mm) and adjust if necessary.

For further technical data and tolerances please refer to page 7.



Torque for tightening screws

M3	1,2 Nm	$\pm 0,2$ Nm
M5	5,5 Nm	$\pm 0,8$ Nm

8 Electrical connection

8.1 Output signals

The electronic evaluation device (PLC, fast counter) records the signal received from the reading head and evaluates them. Different interpolation factors can be used for different measurement resolutions. As with incremental shaft encoders the measurement signals are issued as AB signal.

Signal process – reading head output

U_a = U_e	Phase B	U_{a1}	0°	
	Phase A	U_{a2}	90°	

The preset resolution (after 4-fold evaluation) and the respective output has been fixed for all reading heads as follows:

SFI-plus Id. no.21210 resolution 0.1 mm

SFI-plus Id. no.21211 resolution 1 mm

The reading head issues 2 rectangular signals in quadrature with U_b – 2 V.

Note regarding impulse frequency:



The pole distance of the magnetic measuring tape is 5 mm. The generation of impulse depends on the type of SFI-plus used.

With increasing operating speed the output frequency of the signal impulses increases. This requires the cycle frequency of the downstream counting input to be adjusted accordingly.

For example:

SFI-plus with 0.1 mm resolution:

$v = 1 \text{ m/sec}$ corresponds to 2500 impulses per second = 2.5 kHz

SFI-plus with 1 mm resolution:

$v = 1 \text{ m/sec}$ corresponds to 250 impulses per second = 0.25 kHz

8.2 Connection, cable assignment

The connection cable should be installed mechanically secure, e.g. via energy chain and in metal cable ducting for signal lines.

Avoid chafing of cables.

Colour of cable	Designation
bn / brown	+ DC
bl / blue	- DC
bk / black	A
wt / white	B
Shield	Shield

IMPORTANT:



- All wiring to be carried out with the power disconnected.
- The cable screening and GND (0 V) to be connected with large cross-section in order to ensure that the impedance is as low as possible.
- The cable between the reading head and the downstream electronic device must not be longer than 50 m. If a longer cable is required, please consult the manufacturer.
- Check all electrical connections before commissioning and starting up the system.
- For the installation also take note of the safety notes on page 3.

8.3 Commissioning

- Before switching the system ON, install and check the associated switches and connections to the downstream electronic device.

Danger of injuries



Automatic operation entails a risk of trapping and injury of limbs.

- First disconnect the power from the device.
- Move the unit with the reading head manually and check the counting mechanism.
- Also check the reference switch and possibly also the limit switch for functionality and firm installation.



For closing the unit down, decommissioning and/or recommissioning observe the general rules for technical apparatus.

9 Service

The system is maintenance-free. Nevertheless we recommend that the following points are observed in order to ensure the best possible functionality and service life:

- Check the fitting tolerances between the reading head and measuring tape along the whole length of the measured distance (check for straightness and looseness in the guide)
- Clean the measuring tape surface when dirty (e.g. due to magnetic metal dust, chips)
- Check the condition of the connection cable (indication of broken cable, areas of chafing or trapping)



Any cleaning should only be carried out using substances free from solvent and lint-free cloths!

10 Troubleshooting

Typical faults that may occur during the installation or commissioning:

Fault	Possible cause	Remedy
No impulses are issued. Signal A, B is missing. The measuring system does not count.	No power supply	Connect power supply
	Signal line mixed up	Correct wiring installation
	Programming error	Check inputs and eliminate errors
	Wrong fitting of measuring tape (active side of tape facing downwards).	Fit the measuring tape the other way up (active side of tape facing reading head).
	The protective film for the measuring tape is not suitable	The covering film must be anti-magnetic
	The tolerance for the distance between the reading head and the measuring tape is too large over the whole length.	For the distance tolerance refer to technical data on page 10.
	Reading head touches the measuring tape and is damaged.	Order new reading head and replace the damaged one.
	Reading head damaged due to wrong electrical connection (back voltage on output lines).	Correct wiring layout, order new reading head and replace the damaged one.
Measuring error	The fitting tolerance has not been maintained over the whole measured length	For tolerances refer to technical data on page 10
	Faults have an impact on the measured result	Elimination of faults - see page 7
	External magnetic fields	Elimination of magnetic fields - see page 7
Direction of counting wrong	Signal wiring mixed up	Correct the wiring

11 EC Conformity Statement

Following the meaning of EC Directive EMC 2004/108/EC we, the company bringing this equipment to the market, state in full responsibility that

the SFI-plus length measuring system
complies with the fundamental requirements.

The following related standards apply:

EN 61000-4-2	EN 61000-4-6
EN 61000-4-3	EN 61000-4-8
EN 61000-4-4	EN 61000-6-4
EN 61000-4-5	EN 55011

Company: Parker-Origa GmbH
Industriestr. 8
D 70794 Filderstadt


This product has been developed and produced for determining the position or measuring the length with linear cylinders without piston rods or similar drive and mechanical units.

Filderstadt, 30/3/2005


Johann Asperger
Managing Director

12 Replacement Parts

ITEM.	DESCRIPTION	IDENT-NR.					
		Ø 25	Ø 32	Ø 40	Ø 50	Ø 63	Ø 80
7,8,9,10	READING HEAD WITH MEASURING TAPE, RESOLUTION 0,1 MM (PLEASE STATE LENGTH TO BE MEASURED)	21240	21240	21240	21240	21240	21240
7,8,9,10	EADING HEAD WITH MEASURING TAPE, RESOLUTION 1,0 MM (PLEASE STATE LENGTH TO BE MEASURED)	21241	21241	21241	21241	21241	21241
10	READING HEAD WITHOUT MEASURING TAPE, RESOLUTION 0,1 MM	21210	21210	21210	21210	21210	21210
10	READING HEAD WITHOUT MEASURING TAPE, RESOLUTION 1,0 MM	21211	21211	21211	21211	21211	21211
7,8,9	MEASURING TAPE PER METRE	21235	21235	21235	21235	21235	21235
1,2,3,4, 5,6	CONNECTION SET FOR OSP-P	21213	21214	21215	21216	21217	21218



13 Removal / Disposal



Observe all regulations on the disposal of environmentally damaging materials.

Sales Offices Worldwide

AE – United Arabien Emirates

Dubai
Tel: +971 4 8875600
parker.me@parker.com

AR – Argentina, Buenos Aires
Tel: +54 3327 44 4129

AT – Austria, Wiener Neustadt
Tel: +43 (0)2622 23501-0
parker.austria@parker.com

AT – Austria, Wiener Neustadt
(Europa Oriental)
Tel: +43 (0)2622 23501 970
parker.easteurope@parker.com

AT – Austria, Wiener Neustadt
Parker Origa Pneumatik GmbH

Tel: +43 2622 26071-269

info-hoat-sales.pn@parker-origa.com

AU – Australia, Castle Hill
Tel: +61 (0)2-9634 7777

AZ – Azerbaijan, Baku
Tel: +994 50 2233 458
parker.azerbaijan@parker.com

BE/LX – Belgium, Nivelles
Tel: +32 (0)67 280 900

parker.belgium@parker.com

BR – Brazil, Cachoeirinha RS
Tel: +55 51 3470 9144

BY – Belarus, Minsk
Tel: +375 17 209 9399
parker.belarus@parker.com

CA – Canada, Milton, Ontario
Tel: +1 905 693 3000

CH – Swiss, Etoy
Tel: +41 (0) 21 821 02 30
parker.switzerland@parker.com

CH – Swiss, Otelfingen
Parker Origa AG
Tel: +41 44 846 6860
info-hoch-sales@parker-origa.com

CN – China, Shanghai

Tel: +86 21 5031 2525

CZ – Czechia, Klecany
Tel: +420 284 083 111
parker.czechrepublic@parker.com

DE – Germany, Kaarst
Tel: +49 (0)2131 4016 0
parker.germany@parker.com

DK – Denmark, Ballerup
Tel: +45 43 56 04 00
parker.denmark@parker.com

ES – Spain, Madrid
Tel: +34 902 33 00 01
parker.spain@parker.com

FI – Finland, Vantaa
Tel: +358 (0)20 753 2500
parker.finland@parker.com

FR – France
Tel: +33 (0)4 50 25 80 25
parker.france@parker.com

FR – France, Courtaboeuf Cedex
Parker Origa SAS
Tel: +33 1 69 29 22 00
info-hofr-sales@parker-origa.com

GR – Greece, Atenas
Tel: +30 210 933 6450
parker.greece@parker.com

HK – Hong Kong
Tel: +852 2428 8008

HU – Hungary, Budapest
Tel: +36 1 220 4155
parker.hungary@parker.com

IE – Ireland, Dublin
Tel: +353 (0)1 466 6370
parker.ireland@parker.com

IN – India, Mumbai
Tel: +91 22 6513 7081-85

IT – Italy, Corsico (MI)
Tel: +39 02 45 19 21
parker.italy@parker.com

IT – Italy, Pioltello (MI)
Parker Origa SRL
Tel: +39 02 92 16 65 53
info-hoit-sales@parker-origa.com

JP – Japan, Fujisawa
Tel: +81 4 6635 3050

KR – Korea, Seúl
Tel: +82 2 559 0400

KZ – Kazakhstan, Almaty
Tel: +7 7272 505 800
parker.easteurope@parker.com

LV – Latvia, Riga
Tel: +371 6 745 2601
parker.latvia@parker.com

MX – Mexico, Apodaca
Tel: +52 81 8156 6000

MY – Malaysia, Subang Jaya
Tel: +60 3 5638 1476

MY – Malaysia, Penang
Parker Origa Sdn Bhd
Tel: +60 4 508 10 11
info-hosg-sales@parker-origa.com

NL – Netherlands, Oldenzaal
Tel: +31 (0)541 585 000
parker.nl@parker.com

NL – Netherlands, SL Moerdijk
Parker Origa B.V.
Tel: +31 168 356 600
info-honl-sales@parker-origa.com

NO – Norway, Ski
Tel: +47 64 91 10 00
parker.norway@parker.com

NO – Norway, Drammen
Parker Origa AS
Tel: +47 3 288 08 40
info-hose-sales@parker-origa.com

NZ – New Zealand
Mt Wellington
Tel: +64 9 574 1744

PL – Poland, Varsovia
Tel: +48 (0)22 573 24 00
parker.poland@parker.com

PT – Portugal, Leca da Palmeira
Tel: +351 22 999 7360
parker.portugal@parker.com

RO – Romania, Bucarest
Tel: +40 21 252 1382
parker.romania@parker.com

RU – Russia, Moscow
Tel: +7 495 645-2156
parker.russia@parker.com

SE – Sweden, Spånga
Tel: +46 (0)8 59 79 50 00
parker.sweden@parker.com

SE – Sweden, Kungsör
Parker Origa AB
Tel: +46 227 411 00
info-hose-sales@parker-origa.com

SG – Singapor
Tel: +65 6887 6300

SG – Singapor
Parker Origa PTE Ltd.
Tel: +65 6483 2959
info-hose-sales@parker-origa.com

SK – Slovakia, Banská Bystrica
Tel: +421 484 162 252
parker.slovakia@parker.com

SI – Slovenia, Novo Mesto
Tel: +386 7 337 6650
parker.slovenia@parker.com

TH – Thailand, Bangkok
Tel: +662 717 8140

TR – Turkey, Istanbul
Tel: +90 216 4997081
parker.turkey@parker.com

TW – Taiwan, Taipei
Tel: +886 2 2298 8987

UA – Ukraine, Kiev
Tel: +380 44 494 2731
parker.ukraine@parker.com

UK – United Kingdom, Gloucester
Parker Origa Ltd.
Tel: +44 8700 600655
info-hogb-sales@parker-origa.com

UK – United Kingdom, Warwick
Tel: +44 (0)1926 317 878
parker.uk@parker.com

US – United States of America, Cleveland
Tel: +1 216 896 3000

US – United States of America
Parker Origa Corporation
Tel: +1 630 871 830-0
info-hous-sales@parker-origa.com

VE – Venezuela, Caracas
Tel: +58 212 238 5422

ZA – South Africa,
Kempton Park
Tel: +27 (0)11 961 0700
parker.southafrica@parker.com

Parker-Origa GmbH

Industriestr. 8
70794 Filderstadt, Deutschland
Tel. +49 7185 17030
Fax +49 7158 64870
www.parker-origa.com